

TECHNICAL DATA SHEET

ADVANCED CUT POLISH

Gerko Advanced Cut Polish is the innovative sanding polish for automotive clear coats. Advanced cut polish removes sanding marks and signs of use in the shortest possible time and guarantees a perfect surface. It has an effective removal of paint mists and sanding traces of up to P1500 grain.

With its extremely homogeneous abrasive grain, Gerko advanced cut achieves an extremely high level of cut with an excellent gloss level. Can be polished for prolonged periods without sticking and with low dust formation. Ideally suited to all types of paint.

PROPERTIES

- Polishes and produces gloss in one step
- · Saves time thanks to one-step polishing process
- · High efficiency
- High gloss level
- · Silicone-free and solvent-free
- · Heavy cut, medium cut and finish in 1 bottle
- · Easy clean up
- Waterbased
- Low dust formation

PHYSICAL PROPERTIES

| CODE | DESCRIPTION | COLOUR | PIECES PER BOX | PIECES PER PALLET |
|--------|-------------------------|--------|-------------------|----------------------|
| POL130 | Advanced Cut Polish 1KG | White | 10 | 240 |

GERKO POLIERPROGRAMM

| 1. HEAVY CUT | 2. MEDIUM CUT | 3. FINISH | | | |
|---------------------------|---------------|-----------|--|--|--|
| Gerko Advanced Cut Polish | | | | | |

PRODUCT INFORMATION

| PRODUCT GROUP | CATEGORY | сит | GLOSS |
|----------------------------------|----------|-----|-------|
| Heavy Cut, Medium Cut, Finish | Premium | 8 | 8 |



TECHNICAL DATA SHEET

ADVANCED CUT POLISH

STORAGE

5 - 30°C, avoid frost and direct sunlight

POLISHING TOOLS

- Lambs wool
- Gerko Advanced Cut Foam Pad

RECOMMENDED USAGE

- 1. Clean the surface thoroughly prior to polishing.
- 2. Shake the bottle prior to use and apply a small quantity of the product onto the polishing pad.
- 3. Use the Gerko Advanced Cut Foam Pad.
- 4. If using a new or dry pad, apply sufficient polish to prevent the formation of noticeable holograms.
- 5. Use either a rotary or an orbital polishing machine and use the cross-coating method.

 Apply light pressure at the start of the polishing process. Take away the pressure in the final cycles and increase the speed of the polishing machine by 10%.
- 6. If working on very dry coatings, spray a little water onto the surface to prevent dust formation.
- 7. At first, the polish will seem a little milky and should be worked in until only a slightly transparent/oily film is visible.
- 8. Once you have finished polishing, remove any residue with our Gerko Superior Microfiber cloth, without applying any pressure.
- 9. Whatever the demands of the surface: use Gerko Anti-Hologram Polish with the Gerko Anti-Hologram Foam Pad in order to achieve the best high-gloss finish.